

BARREL FEEDER

TEXAS HUNTER[®]

P R O D U C T S 

BF3C BARREL FEEDER INSTRUCTIONS

1. Place the small metal funnel over the large predrilled outlet hole on the outside bottom of the barrel and secure it using the two sheet metal screws provided.
2. Bolt the mounting brackets for the feeder motor to the predrilled holes (see instructions provided with the timer kit). Be sure these bolts are completely tightened at this time, as the internal funnel will cover them later.
3. *If you are installing the barrel on an EZ Lift Tripod system, refer to those instructions before installing the leg brackets on the barrel.* Attach the three legs to the side of the barrel using the precut holes. Install the 1/4"x1-3/4" bolts, internal brace, lock washers and nuts. **IMPORTANT! Only install the lower leg bolts at this time so that the ABS funnel can be slid into place (the middle leg bolts hold the funnel in place).** Make sure to place bolts from inside the barrel with the lock washers and nuts on the outside. This allows for the optional solar panel to be mounted using additional length of these bolts.
4. Slide the ABS funnel into the barrel and guide the spout into the outlet hole. Push the funnel as far into the barrel as possible for a snug fit – the spout should stick out slightly from the bottom of the barrel. **Note: Once the funnel is in place, the middle leg bolt should be just above the top of the funnel rim – the funnel does not go all the way to the bottom of the barrel and you will not be able to see the bottom leg bolt when looking inside the barrel.**
5. In some cases, it may be necessary to drill a 5/16" hole in the funnel's rim to install the middle leg bolt. Install and tighten the middle and top leg bolts now.

